
4. Light Installations

ASSEMBLY INSTRUCTIONS



Step 1:

Choose the place you would like to set this fixture.

Use a pencial to mark 2 screw holes on the chosen surface. A level may be required.

Step 2:

Use a power drill to drill the holes in the chosen mounting surface

Step 3:

Screw the crossbar(D) into the chosen surface with the included screws (A) and plastic plugs (C).

Step 4:

Remove the protective paper barrier from the adhesive face of the EVA gasket (F) and adhere the gasket to the crossbar and keep them align with. Position the wall plate over the crossbar so that center hole of the wall plate aligns with the center hole in the crossbar.

Put screw (B with ring E) through the center hole of the wall plate and crossbar. Tighten the screw properly to secure the wall plate onto the wall.

Screw the antenna(G) onto the light and adjust to your desired position.

Insert the SD card (not included) which shown as above.

Step 5:


Connect wire from AC adapter (H) into socket on the light, plug into socket on the wall.

5.TROUBLES SHOOTING


Problem	Problem Cause	Corrective Action
Light does not come on at night when motion is detected	No power is being delivered to the light. Another light source is causing the security light to think it is daylight Wiring inside electrical box came loose.	1. Check that ciruit breaker and /or wall switch power is on. 2. Turn off surrounding lights and /or re-aim the sensor head. 3. After turning power off to the light, reconnect any loose wiring.
Security light comes on during the day	Sensor is in a shaded area and is fooled into thinking it is nighttime.	Shine a flashlight onto the light sensor. Relocate security light to where allows enough light enter the se nsor during daytime.
The Light flashes	There is lighting, arc welding, mobile sources or other such unstable light	Avoid to irradiate by such light source




VT-4818 WIFI Floodlight Instruction Manual



Parts List



TOOLS REQUIRED (not included)



CONTENT

1. Mobile APP Download & Installation		
1.1. Android APP download		P3
1.2. IOS APP download		P3
2. Add Camera into the APP		P3
2.1: One key to add device		P3
2.2: LAN search		P4
3. Settings		P4
3.1 Alarm Setting		P4
3.2 Light Setting		P5
3.3 SD Card Setting		P6
3.4 User Setting		P6
3.5 WIFI Setting		P6
3.6 Device Time Setting		P7
3.7 System Setting		P7
3.8 Maul Recording Seting		P7
3.9 Reboot Device Setting		P7
4. Light Installations		P8
5.TROUBLES SHOOTING		P8

3.6 Device Time Setting

Make sure the time shown on recording image is the same with your local time, please set device

time for the first time used.

Step 1: Click the gear ICON showed as picture

Step 2: Click Device Time Setting

Step 3: Choose your time zone

Step 4: Click "Mobile phone time calibration"

Step 5: Click "Done"

3.7 System Setting


tep 1: Click About

Step 2: Click System Setting

Step 3: Click Audio Alarm Setting

Step 4: 3 different sounds can be chosen

Step 5: You can have other settings here if you need.




Will setting

Eval sering

00 ceed setting Only setting

3.8 Mual Recording Seting



Step 1: Click the device you connected to open it

Step:2 Click the recording screen and click the ICON to record the video and click again to stop it

Step 3: Click My Message, all videos recorded by phone can be checked here.

Step 4: Click the videos storaged in My Massage and you can review the videos you took.


3.9 Reboot Device Setting

If you click Reboot Device Seeting, device will be reboot.



Remark: If need help, please click the "About"—"Help" in the APP, there is detailed description for each icon. The Android and IOS interface styles are basically the same, both of them can be operated according to this instructions.

3.3 SD Card Setting



Step 3: SD Card must be formatted for the first time usage.

Step 4: Audio Recording, with the function open, videos will be recorded with sound.

Step 5: Record Coverage, with the function open, videos will be recovered automatically.

SD Card Support: FAT/FAT32, maximum memory size up to 64GB. 64GB SD card can record with

5 days with Audio Recording mode and 7 days without Audio Recording mode.

3.4 User Setting



You can set password here, after setting password, no one can connect WIFI camera without password set.

3.5 WIFI Setting

When WIFI changes, please follow the below steps to reset or re-connect the device.

Step 2: Click WI-FI setting Step 3:

Click WiFi Manager

Step 4: Select the chosen WIFI and cli

Step 5:

Enter the WIFI password

Step 6:

Click Done.



6

- 1. Mobile APP Download & Installation
- 1.1: Android APP download

Search the App "ISmsee" in the Explorer, download & install ISmsee into your phone.

1.2: IOS APP download

Search the iSmsee in the APP Store, then download and install into your phone.

2. Add Camera into the APP

Note:

PLEASE START TO ADD CAMERA TO THE APP AFTER CONNECTING TO POWER FOR AT LEAST 90s. WIFI IS MANDATORY WHEN YOU CONNECT CAMERA INTO APP.

There are 2 ways to connect camera to the App: One Key to Add Device & LAN Search

2.1: One Key to Add Device

Before operating with this device, please connect your phone to WIFI. and then follow all steps shown as below

Step 1: Open the ISmsee App

Step 2: Click" Add Device"

Step 3: Click "One Key to Add"

Step 4: Enter the WIFI password which the mobile connected

Step 5: Click "Start Configuration" and then put the mobile phone speaker aimed at the MIC on the camera.

Step 6: If device can be connected successfuly, you can see the device shown. Click it and then click Done (step 8) without setting password.

Step 7: If you want to set password, you can enter passwrod and click Done (step 8). (device password default is empty)



3

2.2: LAN Search

This can be used after the "One Key to Add Device" connection successfully. Once you had connected by One Key to Add Device, your families can connect by using LAN search Shown as beolow.



3. Settings

Click ICON which circled as below, you will see all setting list shown.



3.1 Alarm Setting

Please follow the belows steps to proceed with alarm settings.

Step 3: Motion detection, open this function, It will send push notification once the image changes.

Step 4: Audio detection, open this function, It will send push notification once voice is detected.

Step 6: PIR detection, open this function, It will send push notification once any thermal object movement is detected.

Step 7: Click Done everytime after you finish every setting.



3.2 Light Setting-Operate light by Phone



Step 3:

---Manual/AUTO setting:

Click ON and then click DONE (step 5): Light will turn on. Lighting time depends on the timer you set.

-- Manual Mode Dwell Time (this is for ON setting)

When you set the light with ON mode, there is 1-10Hs for option. If you set 2 hours. The light will turn on and stay for 2 hours and then turn off and will be into AUTO mode automatically.

Click OFF and then click DONE(step 5): Light will turn off.


Step 4:

Click AUTO and then click DONE (step 5): Light will be into AUTO mode which means light can be turn on automatically when it is detected at DARK environment. Light will turn off after DELAY TIME you set automatically.

Auto Mode Dwell Time (this is for AUTO setting)

When you set this light into AUTO mode, there is 1-30minutes for option. If you set 10 minutes, it means that light will stay on for 10 minutes after detected and then will turn off.

NOTED: PLEASE PAY ATTENTION TO THAT WITH AUTO MODE, LIGHT CAN BE TURN ON AT DARK ENVIROMENT AFTER TRIGGERED AND MAKE SURE THE SETTING IS CORRECT WHICH SHOWN AS BELOW!



Remarks:

If you would like to switch among these 3 fucntions, please note that you should follow rules, never switch from ON to AUTO nor from AUTO to ON directly. You have to click ON \rightarrow OFF \rightarrow AUTO, or AUTO \rightarrow OFF \rightarrow ON.